

Komori GL40 with Tooless Clamp System

Cyrel Plate Mounting Instructions

Step #1: Zero Register coating unit.

Step #2: On Console set Coater Unit for Flexo Plate as shown in pictures below.



Step #3: Remove Blanket and Packing.

Step 4#: Using Spray Mount Adhesive on rubber side of the Under Blanket, lightly spray (on the Lead, Tail and Middle of Under Blanket) then mount to the cylinder. * **DO NOT USE PACKING BAR** *

Step 5#: Mount Cyrel Plate

Suggestions: -Start with a light stripe and light impression. -Save first pull and final register, send to NAPP for evaluation -If it becomes necessary to use paper packing, use full sheets and *DO NOT USE PACKING BAR*